

Pony® Sample Conditioning System Installation, Operation & Maintenance

PSCS[®]





TABLE OF CONTENTS

Safety Warnings	
Product Features	4
Watlow® Controller	
Technical Specifications	5
Product Dimensions & Parts	6
Process & Instrumentation Diagram	8
Electrical Wiring Diagrams	9
Installation Instructions	11
Operation Instructions	12
Maintenance Instructions	12
Oven Industries Controller	
Technical Specifications	13
Product Dimensions & Parts	14
Process & Instrumentation Diagram	16
Electrical Wiring Diagrams	17
Installation Instructions	19
Operation Instructions	20
Maintenance Instructions	20

SAFETY WARNINGS



Failure to abide by any of the safety warnings could result in serious injury or death.

- Standard for Safety Electrical Equipment for Measurement, Control, and Laboratory Use; Part 1: General Requirements (ANSI/UL 61010-1).
- Standard for Safety Electrical Equipment for Measurement, Control, and Laboratory Use; Part 1: General Requirements (CAN/CSA C22.2 No. 61010-1).
- Standard for Safety Explosion-Proof and Dust-Ignition Proof Electrical Equipment for Use in Hazardous (Classified) Locations (ANSI/UL 1203).
- Explosion-Proof Enclosures for Use in Class 1 Hazardous Locations Industrial: Industrial Products (CSA C22.2 No. 30).
- Electrical power must be "OFF" before and during installation and maintenance or personal injury may result. Follow site requirements for Safety Precaution Rules.
- Do not exceed any equipment pressure, or electrical ratings.
- To reduce the risk of fire or explosion, do not install where the marked operating temperature exceeds the ignition temperature of the hazardous atmosphere(s).
- Heated regulator surface temperature will approach temperature limit specified in technical specifications.
- Select a mounting location so that the system will not be subjected to impact or other damaging effects.
- The hazard location information specifying class and group listing of each system is marked on the nameplate.
- Properly ground all equipment to prevent static electric generation.

PRODUCT DESCRIPTION

The Pony® Sample Conditioning System is ideal for sampling wet or dry natural gas when a compact solution mounted directly to the sampling probe is preferred. The PSCS contains a self-limiting block heater, Watlow® PID temperature controller, system temperature limiter, and a single or multistage pressure regulator, all mounted inside a Pony® Heated Probe Enclosure. The close coupled system reduces the opportunity for richer gases to condense within sample tubing and protects analyzers from damage by solids or liquids while delivering a representative sample. The Pony® Sample Conditioning System is the only probe mounted sample conditioning system that can be powered by the heat trace tube bundle, creating a cost effective solution for new or existing locations.

FEATURES

- Patented technology utilizing existing power supplied by heat trace tube bundle
- Molded narrow clam shell design
- Rated for Class 1, Division 1, Group D Locations
- Compatible with Mustang[®]
 CertiSeries[®] line of products
- Steel latching closures

BENEFITS

- Requires no external power or natural gas for proper operation
- Conforms to API 14.1 guidelines for hydrocarbon liquid removal and heat tracing
- Protects probes from temperature and weather fluctuations
- Helps preserve sample integrity
- Prevents Joule-Thomson cooling
- Direct-mount on pipeline fitting between 6" center-to-center threadolets (TOLs)
- Fits over existing probe brands
- Closely coupled to the sample point

Pony® Sample Conditioning System Watlow® Controller Model


TECHNICAL SPECIFICATIONS

Maximum Allowable Operating Pressure	6000 psig (408 BAR) @ 60°F (16°C)
Wetted Parts	316 SS Nace Compliant
Regulator Sample Volume/Cv	0.51 cu. in.
Regulator Cv	0.023
Maintains Sample Gas	Standard set point at 120°F (49°C) Adjustable from 60°F to 400°F (16°C to 204°C)
Regulator Options	MHR® Single-Stage Regulator
	MJTHR [®] Multi-Stage Regulator
Input Supply Voltage Options	115 VAC
	240 VAC
	24 VDC
Cabinet Construction Options	GPR Hotpressed Glass Fiber Reinforced Polyester
	SS Stainless Steel


PRODUCT DIMENSIONS & PARTS



ltem Number	Description
1	Insulated Clamshell Enclosure
2	Watlow® PID Temperature Controller
3	Single or Multi-Stage Heated Regulator
4	Probe Location








Top View

PROCESS & INSTRUMENTATION DIAGRAM


FROM PROBE HEAT TRACE TUBE BUNDLE SINGLE OR MULTI-STACE HEATED REGULATOR SET @ 20# PRV1 PRV1 PRV1 TO G.C. 2215 WATTS PLUS TRACING TUBE BUNDLE VALVE PRV1 45# PRV1 TUBE BUNDLE TUBE BUNDLE TO G.C. 2215 WATTS PLUS TRACING TUBE BUNDLE TUBE BUNDLE TO G.C. 2215 WATTS PLUS TRACING TUBE BUNDLE TUBE BUNDLE TO G.C.

ELECTRICAL & WIRING DIAGRAMS


120 VAC




240 VAC



24 VDC





12

INSTALLATION INSTRUCTIONS

NOMENCLATURE

- **MAOP**—Maximum Allowable Operating Pressure
- **LNG**—Liquid Natural Gas
- **BTU**—British Thermal Unit

TOOLS REQUIRED

- Standard Hand Tools
- Utility Knife

INSTALLATION

The Pony® Sample Conditioning System assembly can be mounted in one of several mounting configurations.

- 1. Mount the Pony® Sample Conditioning System assembly in accordance with previous cautions and warnings.
- 2. Perform the electrical hook up with de-energized conductors.
- 3. Verify the unit that you are hooking up to matches voltage wise with the power supply that you are connecting. Damage to the unit can occur if the wrong source power is applied.
- 4. A seal fitting is required for the power input connection to the controller enclosure to maintain its electrical hazard classification rating.
- 5. For 120 volt single phase input power: Connect the "hot" wire to wiring terminal #1. Connect the "Neutral" wire to wiring terminal #2. Connect the earthing (ground) wire to the green screw in the bottom of the enclosure.
- 6. For 208 or 230 volt single phase input power: Connect one "hot" wire to wiring terminal #1. Connect the "Neutral" to wiring terminal #2. Connect the second "hot" wire to wiring terminal #3. Connect the earthing (ground) wire to the green screw in the bottom of the enclosure.
- 7. For 24 VDC input power: Connect the positive wire to wiring terminal #1. Connect the negative wire to wiring terminal #2. Connect the earthing (ground) wire to the green screw in the bottom of the enclosure.
- 8. A seal fitting is required between the controller enclosure and the regulator heater block.
- 9. Externally connect earthing (grounding) conductors from assembly to equipment ground connections.
- 10. Connections from the controller to the heater block are pre-wired from the factory. If re-placement or troubleshooting is required, refer to the electrical schematic supplied with the unit.

ADJUST THE TEMPERATURE SET POINT

The temperature controller comes from the factory set to 120°F unless otherwise specified. If a different temperature is required, refer to the Watlow® Temperature Controller operation manual for the complete setup and adjustment procedures.

SET REGULATOR PRESSURE

Apply input pressure and adjust the regulator adjustment screw until the desired output pressure is attained. The nut on the adjustment screw may be used to secure the adjustment screw at its set point.

OPERATION INSTRUCTIONS

- 1. Close the cover on the controller enclosure.
- 2. Turn on the electrical supply to the controller.
- 3. Allow a few minutes for the system temperature to stabilize.
- 4. Verify the sample stream supply is shut off.
- 5. Slowly turn on the sample fluid flow to full open to the regulator.
- 6. Adjust the regulator adjusting screw to obtain the desired output pressure.
- 7. Once sample fluid is being regulated, monitor the regulator temperature to verify that the controller is maintaining the set point temperature.
- 8. Verify the pressure and flow to the remote gas chromatograph or analyzer.
- 9. Once the flow is correctly established to the analyzer or gas chromatograph, document the flow value. Do not adjust the flow value unless a calibration check is made on the analyzer.

MAINTENANCE INSTRUCTIONS


- 1. Once system is operational, no routine maintenance is required.
- 2. Monitoring of flow and temperature values is recommended at least annually.

Pony® Sample Conditioning System Oven Industries Controller Model


TECHNICAL SPECIFICATIONS


Maximum Allowable Operating Pressure	2200 psig (150 BAR) @ 60°F (16°C) with Liquid Membrane Separator 6000 psig (408 BAR) @ 60°F (16°C) without Liquid Membrane Separator
Electrical Classification	Class 1, Div 1, Group C, D, & T3 Zone 1 Group IIB, Category 2G, IP66, Ex d IIC T3 Gb
Wetted Parts	316 SS Nace Compliant
Regulator Sample Volume/Cv	0.51 cu. in.
Regulator Cv	Cv = 0.06
Maintains Sample Gas	Standard set point at 120°F (49°C) Adjustable from 60°F to 400°F (16°C to 204°C)
Seals	Teflon [®]
Regulator Options	MHR® Single-Stage Regulator
	MJTHR® Multi-Stage Regulator
Input Supply Voltage Options	115 VAC, 200 Watts, 50/60 Hz, ± 10%
	240 VAC, 200 Watts, 50/60 Hz, ± 10%
	24 VDC
Cabinet Construction Options	GPR Hotpressed Glass Fiber Reinforced Polyester
	SS Stainless Steel

PRODUCT DIMENSIONS & PARTS




ltem Number	Description
1	Insulated Clamshell Enclosure
2	Oven Industries Temperature Controller
3	Single or Multi-Stage Heated Regulator
4	Probe Location







PROCESS & INSTRUMENTATION DIAGRAM



ELECTRICAL & WIRING DIAGRAMS



120/240 VAC 50/60 Hz



INSTALLATION INSTRUCTIONS

NOMENCLATURE

- **MAOP**—Maximum Allowable Operating Pressure
- **LNG**—Liquid Natural Gas
- **BTU**—British Thermal Unit

TOOLS REQUIRED

- Standard Hand Tools
- Utility Knife

INSTALLATION

The Pony® Sample Conditioning System assembly can be mounted in one of several mounting configurations.

- 1. Mount the Pony® Sample Conditioning System assembly in accordance with previous cautions and warnings.
- 2. Perform the electrical hook up with de-energized conductors.
- 3. Verify the unit that you are hooking up to matches voltage wise with the power supply that you are connecting. Damage to the unit can occur if the wrong source power is applied.
- 4. A seal fitting is required for the power input connection to the controller enclosure to maintain its electrical hazard classification rating.
- 5. For 120 volt single phase input power: Connect the "hot" wire to wiring terminal #1. Connect the "Neutral" wire to wiring terminal #2. Connect the earthing (ground) wire to the green screw in the bottom of the enclosure.
- 6. For 208 or 230 volt single phase input power: Connect one "hot" wire to wiring terminal #1. Connect the "Neutral" to wiring terminal #2. Connect the second "hot" wire to wiring terminal #3. Connect the earthing (ground) wire to the green screw in the bottom of the enclosure.
- 7. For 24 VDC input power: Connect the positive wire to wiring terminal #1. Connect the negative wire to wiring terminal #2. Connect the earthing (ground) wire to the green screw in the bottom of the enclosure.
- 8. A seal fitting is required between the controller enclosure and the Mustang® Heated Regulator heater block.
- 9. Externally connect earthing (grounding) conductors from assembly to equipment ground 6 connections.
- 10. Connections from the controller to the heater block are pre-wired from the factory. If replacement or troubleshooting is required, refer to the electrical schematic supplied with the unit.

ADJUST THE TEMPERATURE SET POINT

- The temperature controller is pre-set at the factory to 120°F unless otherwise specified.
- To adjust the Oven Industries controller in the field, only adjust the center set screw in small increments. The pre-set adjustment has the potentiometer slot set between 6 o'clock and 7 o'clock to achieve the correct 120°F temperature.
- When adjusting the center potentiometer, a slight 1/16" turn will adjust between 5 and 10 degrees Fahrenheit. Adjustments clockwise increases the temperature and counter-clockwise decreases the temperature. The adjustment is very sensitive and a small turn of the potentiometer can make a large change in the output.
- Once the slight adjustment is made, let it stabilize to see if it reaches your desired temperature. Repeat small adjustments until your desired temperature is reached.

SET REGULATOR PRESSURE

Apply input pressure and adjust the regulator adjustment screw until the desired output pressure is attained. The nut on the adjustment screw may be used to secure the adjustment screw at its set point.

21

OPERATION INSTRUCTIONS

- 1. Close the cover on the controller enclosure.
- 2. Turn on the electrical supply to the controller.
- 3. Allow a few minutes for the system temperature to stabilize.
- 4. Verify the sample stream supply is shut off.
- 5. Slowly turn on the sample fluid flow to full open to the regulator.
- 6. Adjust the regulator adjusting screw to obtain the desired output pressure.
- 7. Once sample fluid is being regulated, monitor the regulator temperature to verify that the controller is maintaining the set point temperature.
- 8. Verify the pressure and flow to the remote gas chromatograph or analyzer.
- 9. Once the flow is correctly established to the analyzer or gas chromatograph, document the flow value. Do not adjust the flow value unless a calibration check is made on the analyzer.

MAINTENANCE INSTRUCTIONS

- 1. Once system is operational, no routine maintenance is required.
- 2. Monitoring of flow and temperature values is recommended at least annually.

Analytically Accurate® **TECHNOLOGY**

About Mustang Sampling

Mustang Sampling, LLC is the innovator of Analytically Accurate® solutions within sample conditioning systems. We provide custom solutions of products and services globally to the Natural Gas, Renewable Natural Gas (RNG), Natural Gas Liquids (NGL), and Liquefied Natural Gas (LNG) industries. Mustang Sampling continues to pioneer integrated control systems, allowing our customers to maintain phase stability from sample extraction at the source through sample analysis. Our products are continuously improved and subjected to the highest quality standards which provides our customers with the best sample conditioning solutions.

Mustang Sampling, LLC 43 Ritmore Glen Ravenswood, WV 26164 P: +1 304 273 5357 F: +1 304 273 2531

info@MustangSampling.com www.MustangSampling.com

Copyright © 2019-2021Mustang Sampling.
All rights reserved.
Mustang Sampling®, Mustang®, PSCS®, Pony®, CertiSeries®, MHR®, MJTHR® and Analytically Accurate® are registered trademarks of Mustang Sampling, LLC Watlow® is a registered trademark of Watlow Electric Manufacturing Company.
Teflon® is a registered trademark of The Chemours Company.

U.S. Patents 7,162,933; D674,052 S

No part of this publication may be reproduced in any material form without the written permission of Mustang Sampling, LLC.

MS-IOMPSCS.v6-EN-P October 2021 Supersedes: MS-IOMPSCS.v5-EN-P